


N01 23976

6R80 3RD GEAR



- CIRCUIT/PRESSURE**
- PUMP SUCTION/ PUMP SUPERCHARGE FLOW
 - LINE PRESSURE
 - REGULATED LINE PRESSURE
 - TRANSMISSION FLUID COOLER FEED/LUBRICATION
 - TCC RELEASE PRESSURE
 - NO PRESSURE (CIRCUIT NOT USED / VALVE EXHAUST)
 - EXHAUST CIRCUIT
 - SOLENOID FEED CIRCUIT/FULL SOLENOID PRESSURE
 - VARIABLE SOLENOID PRESSURE

- SYMBOLS**
- ⊘ BALL CHECK
 - ↔ FLUID DIRECTION
 - ⊘ SHUTTLE BALL
 - ✓ EXHAUST
 - ⊘ SOLENOID DAMPER
 - VALVES/PUCKS/PISTONS

MANUAL VALVE P R N D 3 2 1